


UNIMOG



**Anbau-Bedienungsanleitung und
Ersatzteil-Liste**

Selbstbergungsseilwinde

Typ F 64 M1SE



**UNIMOG U52/421 - U60/421 - U72/403 - U80/413 - U84/406 -
U110/416 - U125/416 - U82/404 - U110/404 - U 120/425 - U 150/425 -
U60/421T - U110/416T - UK60 - MB-trac 65/70 - MB-trac 800**